

Tether Connector Strap Installation

Use the tether connector strap to create an acceptable rear facing tether anchor point when a built-in anchor point is not available.

IMPORTANT: Only use the tether connector strap for Swedish Method rear facing installation.

- 1 Follow instructions in the user guide to install the restraint rear facing.
- 2 Locate a structural metal part, that is bolted to the floor of the vehicle and does not interfere with vehicle seat adjustment, where the tether connector strap can be attached (e.g., seat frame bar, seat belt anchor attached to the floor, or vehicle seat leg).
- 3 Wrap the connector strap around the structural metal part.
- 4 Thread the connector plate through the webbing loop on the opposite end of the strap.
- 5 Pull the connector plate until the strap is tight around the structural metal part.
- 6 Use the circular opening in the connector plate as an attachment point for the hook on the tether strap.
- 7 Follow instructions in user guide to complete rear facing tether installation.

