

Adjuster Strap Replacement

Items needed for Adjuster Strap Replacement

- Adjuster Strap Assembly
- Scissors

Use the procedure below to replace the adjuster strap on your Britax Marathon or Wizard.

1 Using scissors, carefully cut through old adjuster strap (Fig. A).

2 Pull back fabric cover on the front of the restraint to expose adjuster area.

3 Lift adjuster release lever, then pull old adjuster strap out of the adjuster (Fig. B).

4 Slide shoulder harness straps off each side of metal yoke (Fig. C). Discard old adjuster strap and yoke.

5 Feed new adjuster strap behind belt guard (Fig. D).

6 Feed the new adjuster strap from the rear to the front through the guide on the underside of the seat (Fig. E).

7 Route strap over bar at rear of adjuster then lifting adjuster release lever, feed strap under the lever pulling strap through to front (Fig. F).

8 Verify that the adjuster strap is not twisted then reattach yoke to shoulder harness.

9 Replace cover to its normal position.

